

Installation of HWAM 3055 steel smoke deflector plate



The right, vertical skamol part has a minor groove, which allows the smoke deflector plate more space during installation (upper right red arrow).

Please, also note the other arrow, which is pointing at the corner where the right, rear most corner of the smoke deflector plate achieve most clearance during installation.



Start with positioning the right, foremost corner of the smoke deflector plate beyond the small groove, and as much to the right as possible.



Use the right, foremost corner of the smoke deflector plate as a turning point and turn the smoke deflector plate carefully, so the right, rearmost corner reach the point as shown (see also the red arrow on the first picture).

Be careful not to harm the skamol to the left during this process!

A little hint: With a sort of small vibrating of the smoke deflector plate, it seems easier to have the left part of the smoke deflector plate passing the skamol side.



When the smoke deflector plate has passed the left side of the skamol, it will easily line up horizontally, and it can be lowered in position.