



2.1 DIMENSIONS

2.1.1 STOVE



2.1.2 NPI45 COMPLETE WITH NI800 FLASHING



\*In order to install flashing flush to a finished wall and centered within the opening, the front opening of the fireplace or enclosure must be this wide.